

# Power Supplies

Server or Desktop Pcs

Model	PDF MANUAL
Model	<a href="#">to_kzcom-B1Lyq1C2YWS</a>
Model	<a href="#">to_kzcom_65793a0977c7ec679dee75b4d6c2bf0d97f9</a>
Model	<a href="#">to_kzcom_SF_PLATINUM_User_Manual</a>
Model	<a href="#">to_kzcom_pp11_mn</a>
	<a href="#">to_kzcom_pp11_db_en</a>
	<p>Load on power supply</p> <p>Note</p> <ul style="list-style-type: none"> <li>9.3 dB(A) @ 20%</li> <li>9.6 dB(A) @ 50%</li> <li>21.6 dB(A) @ 100%</li> </ul> <p>40 db 35 db 30 db 25 db 20 db 15 db 10 db 5 db</p> <p>10% 20% 30% 40% 50% 60% 70% 80% 90% 100%</p> <p>Load</p> <p>580 mm 24 pin</p> <p>600 mm 12V PI connector 12V PI connector</p> <p>500 mm PCI (1+2 pin) PCI (1+2 pin)</p> <p>300 mm SATA SATA IDE IDE</p> <p>300 mm SATA IDE IDE</p> <p>300 mm SATA SATA SATA</p> <p>150mm 150mm 150mm</p>
	<a href="#">to_kzcom_171122_E11_db_en</a>

